TOP AND CABINET PARTS

AUTOMATIC WASHER

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)

KitchenAid®



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	357213	Nut, Push−In (2)
2		Top
	3949481	White
	3949482	Almond
	3949483	Biscuit
3	62750	Spacer, Cabinet To Top (4)
4	21097	Pad, Hinge
5		Cabinet
	3950968	White
	3950969	Almond
	3952698	Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
8	3356311	Screw & Washer, Lid Switch (2)
11	3949237	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19		Lid
	3362329	White
	3362330	Almond
	3362331	Biscuit
20	358684	Strike, Lid Switch
22	3360787	Bumper, Lid
23	356907	Rivet, Plastic
28	384435	Screw, 10−16 x 1/2 (5)
31	90016	Clip, Harness
34	3362952	Dispenser, Bleach
36	3349654	Sound−Damper (Cabinet)

REAR PANEL PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR PANEL PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	16123	Washer, Water Inlet Hose (4) (1−1/16 x 5/8)
2	3349365	Hose, Sensor Upper
3	3949378	Hose, Water Inlet (2)
4	3357027	Nozzle, Drain Hose
5	387402	Hinge, Console (2)
6	3357978	Panel, Rear
7	62747	Pad, Rear Panel
8	3951609	Hose, Drain (4 ft.)
	661577	Hose, Drain (9 ft.) (Not Included)
	3357090	Extension, Drain Hose (21 Inches) (Not Included.)
9	3357319	Hose, Vacuum Break
10	9740848	Screw
15	3949468	Strain Relief, Power Cord
18	3952164	Valve, Water Mixing
19	90864	Screw, 10−24 x 3/8 (2)
21	370451	Clamp, Hose 272846 (Alt.) 353367 (Alt.)
22	3352282	Sensor, ETC−Inline
23	371503	Clamp, Hose
24	387606	Break, Vacuum
25	63290	Support, Rear Panel
26	3361809	Connector, Drain Hose
27	356138	Clamp, Hose
28	3359816	Hose, Pump To Drain Connector
30	3363366	Clamp, Hose
31	371507	Clamp, Hose
32	3951449	Hose, Pump To Tub
33	62863	Screw, 10−16 x 3/8
34	3357011	Screw, 10−16 x 1/2
35	3348424	Shield, Suds
36	3366913	Clamp, Drain Hose

AGITATOR, BASKET AND TUB PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser, Rinse
2	358237	Screw & Washer (5−16−24 x 1)
3	3950581	Clothes Mover
4	3950580	Agitator
5	63851	Tub Ring
6	3359585	Gasket, Tub Ring
7	21366	Nut, Spanner
8	3951987	Basket
9	3361948	Filter, Plate
11	388893	Tub (Includes Item 15)
12	389140	Block, Basket Drive
13	383727	Gasket, Centerpost
14	3347780	Hose, Pressure Switch
15	3948705	Hose, Bleach
17	3366877	Dog, Agitator Clutch (4)
18	3347290	Cap, Barrier
19	3348855	Seal, Inner Auger
20	3363663	Cam−Driven
21	3363661	Bearing−Driven Cam
22	3350389	Spacer, Thrust
23	3354845	Clip, Agitator
24	3355921	Washer, Agitator
25	3950579	Agitator (Complete Asy.)

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 12 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8		Spring, Clutch (Not Serviced)
9	3360630	Gearcase (Complete) (Refer to Page 11 For Further Breakdown)
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	3364003	Coupling, Motor And Isolation
14	3946532	Shield, Motor
16	3357334	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	3350418	Motor, Main Drive
20	62850	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3363892	Pump (Complete)
23	3949170	Capacitor, Motor Start
24	357030	Clamp, Capacitor
25	62863	Screw, Capacitor Mounting
28	3387485	Screw (2) #10−16 x 5/8
29	3355454	Clip, Anti−Rattle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3387485	Screw, Bracket Mounting (10−16 x 5/8) (6)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring, Suspension (3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2) 10−16 x 3/8 (2)
10	3948989	Clip, Grounding
11	357640	Screw, 10−16 5/8
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus, 6, 7, 8, 9, 18 & 26)
20	3976301	Sound, Absorber
21	3359452	Nut, Lock (3/8−16)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring
27	3350281	Hanger−Drain Hose
28	3350282	Clip−Snap In (Drain Hose)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3952518	Timer, Control 60Hz. (Motor Not Serviced)
2	3950420	Switch, Water Level
3	3948608	Bracket, Control
4		Cap, End (L.H.)
	3360570	White
	3360572	Almond
	3360574	Biscuit
5	694419	Mini, Buzzer
6	90767	Screw 8A x 3/8
7	3950354	Switch, Water Temperature
8	388326	Screw
9		Console, Panel
	3952531	White
	3952532	Almond
	3952533	Biscuit
10		Cap, End (R.H.)
	3360567	White
	3360569	Almond
	3360573	Biscuit
11	3952578	Switch, Rotary
12		Knob, Timer
	3361052	White
	3361053	Almond
	3952694	Biscuit
13	3361228	Switch, Rotary
14	90864	Screw, 10−24 x 3/8
15	96435	Screw (2)
16		Knob, Control
	3949700	White
	3949701	Almond
	3949704	Biscuit
17	3407125	ETC Control
18		Dial, Timer
	3361174	White
	3361175	Almond
	3952695	Biscuit
19	688805	Clip, Knob
20	3952690	Harness, Wire (For Detail See Pages 13 & 14)
21	3948063	Cord, Power

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3976259	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (1−1/16 x 5/8) (4)
4	3359452	Nut, Lock (3/8−16)
5	389102	Foot, Front (2)
7	3366912	Clamp, Hose

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

Part No.	DESCRIPTION
LIT3951188	Sheet, Installation Instructions
LIT3950451	Guide, Use and Care
LIT3952474	Energy Guide
LIT3950739	Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

Part No.	DESCRIPTION
72017	White
72107	Almond
4392899	Biscuit
72110	New Gold

PAINT, PRESSURIZED SPRAY (13 oz.)

Part No.	DESCRIPTION
350938	Primer, Gray
350930	White
350956	Almond
4392901	Biscuit
261890	New Gold

PAINT, BULK (1 qt.)

Part No.	DESCRIPTION
799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit (Uncut)
261891	New Gold (Uncut)

OIL

Part No.	DESCRIPTION
350572	Oil, Gearcase (16 Oz.)

LUBRICANT

Part No.	DESCRIPTION
285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

Part No.	DESCRIPTION
285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

SHIPPING KIT

Part No.	DESCRIPTION
3348675	Shipping Kit

COUPLING

Part No.	DESCRIPTION
384496	Coupling, Hose

ACCESSORY PARTS

Part No.	DESCRIPTION
367031	Drain Protector
89121	Stand−Pipe Kit
285320	Siphon Break Kit

GEARCASE PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10−24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

GC−215C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

	285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)



WH2G

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0

(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness
2	388498	Clip, Harness
3	3347812	Clip, Harness
4	3352501	Clip, Harness
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	389379	Retainer, (Suds Models)
8	352090	Timer, Block Disconnect (White)
9	352089	Timer, Block Disconnect (Black)
10	62889	Receptacle, Terminal (3−Way) (Lid Switch) (Use Term.94613) Or 94614.)
11	353424	Plug, Terminal (3−Way) (Power Cord) (Use Term.94613)
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)
13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)
14	3347243	Block, Disconnect (Use Term. 352088)
15	63523	Protector
16	717252	Connector (2−Way) (Use Term.94614)
17	387566	Plug, Terminal (4−Way) (Power Cord) (Use M3 Screws)
18	3352944	Clip, Harness
19	3390423	Block, Disconnect (12−Way) (Timer) (Use Term. 94613)
20	3347730	Receptacle (6−Way) (Use Term. 94613)
21	388818	Plug, Terminal (12−Way) (Use Term. 94613 Or 94614.)
22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)
23	3349494	Connector, Etc
24	60687	Connector, Relay (Use Term.308569)
25	3407125	E.T.C. Control
26	3948617	Connector (T.P.A.) (3−Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.)
27	3360056	Connector (T.P.A) (3−Circuit) (Pressure Switch) (Use Term.3948619 OR 3948620.)
28	3354925	Block, Connector (Cold Valve) (Use Term.693217)
29	3354926	Block, Connector (Hot Valve) (Use Term.693217)
30	3948615	Connector (T.P.A.) (6−Circuit) (Temp. Switch) (Use Term.3948619 OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

WATER SYSTEM PARTS

For Models: KAWS850GQ0, KAWS850GZ0, KAWS850GT0
(White) (Almond) (Biscuit)



WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)